



Sony ICF-C1T Screen Replacement

When your screen is too bright or it has a lot of scratches on it, you can easily replace the screen or add a sheet of tint to the backside of it.

Written By: amber woolery



INTRODUCTION

We are going to show you how to fix a screen that is too bright and possibly has a lot of scratches.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Super Glue](#) (1)
-

Step 1 — Screen




- Using a phillips head screwdriver, remove 4 (14mm) screws from the bottom of the clock.
- ⚠ Make sure the clock is unplugged from the wall and the replacement battery has been taken out of the clock to prevent harm from you and to the clock.

Step 2




- Insert the plastic opening tool to pry apart the top and sides of the device gently.


Step 3




- Carefully pull top of the device away from the rest of the clock to expose the inside.

 Use caution when pulling top of clock off as the clock display is located directly behind the face plate and still connected by multiple wires.

Step 4




- Gently add pressure to the inside of the screen so that a small area is loosened enough to be able to use an opening tool.

 Be careful not to use too much pressure on the plastic as to break it.

- Use the plastic opening tool to separate the screen from the device.

Step 5



- Once the tinted sheet is out of place you can apply the tinted spray to dim the brightness.
- Another way to solve the brightness problem is to apply a tinted color sheet protector.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-27 06:49:39 AM.